

Version: EN-UM-1.4



# USER MANUAL

---

## Single-phase ESS Inverter

## HISTORY

VERSION	ISSUED	COMMENTS
1.0	17-Mar.-23	First release
1.1	26-Jul.-23	Update the DO descriptions in 9-Pin of 4.6 Communication Connection section.
1.2	28-Aug.-23	Update the contents of the CT.
1.3	13-Mar.-24	Update description of the parallel connection.
1.4	10-Apr.-24	Update wire spec. of battery/PE/AC.

# Preface

## About This Manual

This manual describes the installation, connection, the use of APP, commissioning and maintenance etc. of ESS inverter. Please first read the manual and related documents carefully before using the product and store it in a place where installation, operation and maintenance personnel can access it at any time. The illustration in this user manual is for reference only. This user manual is subject to change without prior notice. (Specific please in kind prevail.)

## Target Group

ESS inverters must be installed by professional electrical engineers who have obtained relevant qualifications.






## Scope

This manual is applicable to the following inverters:

- 3K6HB-60
- 3K68HB-60
- 4K6HB-60
- 4K6HB-120
- 5KHB-120
- 5KHB-60
- 6KHB-120
- 6KHB-60
- 4K6AC
- 5KAC
- 6KAC

## Conventions

The following safety instructions and general information are used within this user manual.

 <b>DANGER</b>	Indicates an imminently hazardous situation which, if not correctly followed, will result in serious injury or death.
 <b>WARNING</b>	Indicates a potentially hazardous situation which, if not correctly followed, will result in serious injury or death.
 <b>CAUTION</b>	Indicates a potentially hazardous situation which, if not correctly followed, could result in moderate or minor injury.
 <b>NOTICE</b>	Indicates a potentially hazardous situation which, if not correctly followed, could result in equipment failure to run, or property damage.
 <b>NOTE</b>	Call attention to important information, best practices and tips: supplement additional safety instructions for your better use of the ESS inverter to reduce the waste of you resource.

# CONTENTS

## **Preface**

About This Manual

Target Group

Scope

Conventions

## **1. Safety**

1.1 Symbols Used

1.2 Safety Precaution

## **2. Product Introduction**

2.1 Overview

2.2 Product Appearance

2.3 Model Definition

## **3. Installation**

3.1 Packing List

3.2 Selecting the Mounting Location

3.3 Mounting

## **4. Electrical Connection**

4.1 Grounding

4.2 GRID/BACKUP Connection

4.3 Battery Connection

4.4 PV Connection

4.5 Meter/CT Connection

4.6 Communication Connection



## **5. System Operation**

5.1 Inverter Working Mode

5.2 Startup/Shutdown Procedure

## **6. Commissioning**

6.1 Inspection

6.2 Commissioning Procedure

## **7. User Interface**

7.1 LED

7.2 App Setting Guide

## **8. Maintenance**

8.1 Routine Maintenance

8.2 Inverter Troubleshooting

8.3 Removing the Inverter









## **9. Technical Specifications**

# 1. Safety

Before using the inverter, please read all instructions and cautionary markings on the unit and in this manual. Put this manual to a place where you can take it easily.

Our ESS inverter strictly conforms to related safety rules in design and test. Please follow the local laws and regulations during installation, operation and maintenance. Incorrect operation may cause injury or death to the operator or a third party, and damage to the inverter and other properties belonging to the operator or a third party.

## 1.1 Symbols Used

Safety Symbol	Description
	Danger of high voltage! Only qualified personnel may perform work on the inverter.
	Residual voltage exists after the inverter is powered off. It takes 5 minutes for system to discharge to a safe voltage.
	Danger of hot surface
 Do not disconnect under load!	Do not disconnect under load, otherwise there will be a danger of fire.
	Environmental Protection Use Period
	Refer to the operating instructions
	Don't dispose of the inverter with the household waste.
	Grounding terminal

## 1.2 Safety Precaution

- Installation, maintenance and connection of inverters must be performed by qualified personnel, in compliance with local electrical standards, wiring rules and requirements of local power authorities and/or companies.
- The temperature of some parts of the inverter may exceed 60°C during operation. Do not touch the inverter during operation to avoid being burnt.
- Ensure children are kept away from inverters.
- Don't open the front cover of the inverter. Apart from performing work at the wiring terminal (as instructed in this manual), touching or changing components without authorization may cause injury to people, damage to inverters and annulment of the warranty.
- Static electricity may damage electronic components. Appropriate methods must be adopted to prevent such damage to the inverter; otherwise the inverter may be damaged and the warranty annulled.
- Ensure the output voltage of the proposed PV array is lower than the maximum rated input voltage of the inverter; otherwise the inverter may be damaged and the warranty annulled.
- When exposed to sunlight, the PV array generates dangerous high DC voltage. Please operate according to our instructions, or it will result in danger to life.
- PV modules should have an IEC61730 class A rating.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Completely isolate the inverter before maintaining. Completely isolate the inverter should: turn off the PV switch and disconnect the PV terminal, battery terminal, and AC terminal.
- After the inverter is powered off, the remaining electricity and heat may still cause electric shock and body burns. Do not touch parts of inverter for 10 minutes after disconnection from the power sources.
- Prohibit inserting or pulling the AC and DC terminals when the inverter is running.
- In Australia, the inverter internal switching does not maintain the neutral continuity. And neutral integrity must be addressed by external connection arrangements.
- Don't connect ESS inverter in the following ways:
  - The BACKUP Port should not be connected to the grid;
  - A single PV panel string should not be connected to two or more inverters.


## 2. Product Introduction

### 2.1 Overview

#### Hybrid Inverter

The hybrid inverters are high-quality inverter which can convert solar energy to AC energy and store energy into battery. Typically, an ESS inverter system consists of PV array, ESS inverter, battery, loads and electricity sensor.


The energy generated by inverter can be preferentially supplied to its self-consumption, stored in the battery for future use or fed into public grid.



#### AC Couple Inverter

The AC couple inverters are high-quality inverter which can store energy into battery.


The inverter can be used to optimize self consumption, store in the battery for future use or feed into public grid. Work mode depends on the battery and user's preference. It can provide power for emergency use during the grid lost by using the energy from battery.




## 2.2 Product Appearance

### 2.2.1 Hybrid Inverter

#### Structure A




#### Structure B




#### The Bottom View of Hybrid Inverter

##### Structure A



##### Structure B









1. Battery Connect Terminals
2. PV Switch
3. PV Input Terminals
4. COM1 Ports  
(USB, PARAL, RS485, DRM,CT/METER,  
BMS, NTC/RMO/DRY )
5. COM2 Port  
(GPRS/WIFI/LAN)
6. BACKUP Output Terminal
7. GRID Output Terminal
8. External Protection Ground Terminal

LED Indicators	Description
	PV
	Battery
	Grid
	Backup
	Communication
	Alarm


Note: Structure A and B only differ in their size.

## 2.2.2 AC Couple Inverter



LED Indicators	Description
	Battery
	Grid
	Backup
	Communication
	Alarm

### The Bottom View of AC Couple Inverter




1. Battery Connect Terminals
2. COM1 Ports  
(USB, PARAL, RS485, DRM,CT/METER, BMS, NTC/RMO/DRY )
3. COM2 Port  
(GPRS/WIFI/LAN)
4. BACKUP Output Terminal
5. GRID Output Terminal
6. External Protection Ground Terminal

Note: The appearances of hybrid inverter and AC couple inverter are presented in detail in this section. The following chapters only illustrate hybrid inverter structure A.

## 2.3 Model Definition


The letters in the product model have the specific informations.  
(Take 5KHB-60/4K6AC as examples.)



### 3. Installation

#### 3.1 Packing List

After unpacking, please check the following packing list carefully for any damage or missing parts. If any damage or missing parts occurs, contact the supplier for help.




Number	Quantity	Description
A	1	Inverter
B	1	Mounting bracket
C	1	File package
D	2/2	PV connector group (PV+/PV-); N/A for AC Couple
E	1	Backup connector
F	1	Grid connector
G	2	Battery connector
H	1	Meter (Optional)
I	1	CT
J	3	M12 Expansion bolt
K	1	M6 Security screw
L	1	GPRS/WIFI/LAN module (Optional)
M	1	9-Pin terminal
N	2	4-Pin terminal
O	1	Removal tool for PV connector
P	1	Removal tool for Grid/Backup connector
Q	1	Battery temperature sensor (Optional)



### 3.2 Selecting the Mounting Location


#### 3.2.1 Installation Environment Requirements

- a. With an IP65 protection rating, the inverter can be mounted indoors or outdoors.
- b. The mounting location must be inaccessible to unrelated personnel since the enclosure and heat sinks are extremely hot during operation.
- c. Do not install the inverter in areas containing highly flammable materials or gases.
- d. To ensure optimum operation and long service life, the ambient temperature must be below 50°C.
- e. The inverter must be mounted in a well-ventilated environment to ensure good heat dissipation.
- f. To ensure long service life, the inverter must not be exposed to direct solar irradiation, rain, or snow. It is recommended that the inverter be mounted in a sheltered place.
- g. The carrier where the inverter is mounted must be fire-proof. Do not mount the inverter on flammable building materials.
- h. Do not install the inverter in a rest area since it will cause noise during operation.
- i. The installation height should be reasonable, and please make sure it is easy to operate and view the display.
- j. Product label and warning symbols shall be clear to read after installation.
- k. Please avoid direct sunlight, rain exposure, snow cover.





### 3.2.2 Mounting Requirements

Mount the inverter vertically or tilted backward by max 15°. The device can not be installed with a wrong mode and the connection area must point downward.



### 3.2.3 Installation Space Requirements

To ensure the inverter normally and easy to operate, there are requirements on available spaces of the inverter, e.g. to keep enough clearance. Refer to the following figures.




### 3.3 Mounting

Before mounting the inverter, you have to prepare expansion screws and a security screw.

#### Step 1. Install the mounting bracket

1. Use a level ruler to mark the position of the 3 holes on the wall. Refer to Figure a. And drill 3 holes, 16mm in diameter and 55mm in deep. Refer to Figure b.
2. Knock the expansion screw kit into the hole together with a hammer. Refer to Figure c.  
*Note: Do not remove the nut unit in this step.*
3. After tightening 2-3 buckles, the expansion bolts are tight and not loose, and then unscrew the bolts, spring washer, gasket. Refer to Figure c.
4. Install and fix the mounting bracket on the wall. Refer to Figure d.



#### Step 2. Install the inverter on the mounting bracket. Then lock the inverter using the security screw. Refer to Figure e, Figure f.

<p>Set bracket level.</p> <p><b>a</b> Mark the holes position on the wall.</p>	<p>Ø: 16mm; Depth: 55mm</p> <p><b>b</b> Drill the holes.</p>	<p><b>c</b> Install expansion bolts. (M12; 3 suites)</p>
<p><b>d</b></p>	<p><b>e</b></p>	<p><b>f</b> M6 screw; 2.5N·m</p>

<p><b>DANGER</b></p>	<p>Before drilling the hole on the wall, ensure no damage on the electric wire or water pipe inside the wall.</p>
----------------------	---


<p><b>CAUTION</b></p>	<p>To prevent potential damages and injuries from inverter falling down, please hang the inverter on the bracket, do not loosen grip unless confirm the inverter is well-mounted.</p>
-----------------------	---

## 4. Electrical Connection

This chapter shows the detailed electrical connections of ESS inverter. And PV connection is N/A for AC Couple inverters. The following illustration only uses the hybrid inverters as an example.

Standard Non-Parallel Connection Wiring Diagram

Diagram 01



- ① BMS communication cable
- ② CT/Meter communication cable

**Note:**

1. PV related contents are N/A for AC Couple inverter.
2. BMS communication connection is only applied for lithium battery.
3. Meter is optional.
4. About breakers:
  - DC breaker on BATTERY side: 150A
  - AC breaker on Backup port  $\geq 50A$
  - AC breaker on Inverter side  $\geq 50A$




**DANGER**

Ensure that the inverter and all cables to be installed have been completely powered off during the whole process of installation and connection. Otherwise, fatal injury could be caused by the high voltage.

**Single Phase Parallel Connection Wiring Diagram  
Scheme A: N≤5**

**Diagram 02**



- ① Parallel communication connection
- ② CT/Meter communication connection
- ③ BMS communication connection

\* CT/Meter and BMS communication cables can be connected to any inverter, but they must be inserted into the same inverter and we call this inverter No. 1 inverter.

**Note for Scheme A:**

1. PV related contents are N/A for AC Couple inverter.
2. BMS communication connection is only for lithium battery.
3. It is necessary to turn the DIP switch of No. 1 inverter and No. N inverter to “ON” in parallel connection mode.
4. Under parallel connection mode, it is necessary to connect APP to one of inverters and go to [Console > Hybrid Setting > Other](#) page to enable [Parallel mode](#) on APP.
5. About breakers:  
DC breaker on BATTERY side: 150A  
AC breaker on Backup port  $\geq 50A$   
AC breaker on Inverter side  $\geq 50A$




**DANGER**

Ensure that the inverter and all cables to be installed have been completely powered off during the whole process of installation and connection. Otherwise, fatal injury could be caused by the high voltage.

**Single Phase Parallel Connection Wiring Diagram  
Scheme B: N>5**

Diagram 03



- ① Parallel communication connection
- ② CT/Meter communication connection
- ③ BMS communication connection

\* CT/Meter and BMS communication cables can be connected to any inverter, but they must be inserted into the same inverter and we call this inverter No. 1 inverter.

**Note for Scheme B:**

1. PV related contents are N/A for AC Couple inverter.
2. BMS communication connection is only for lithium battery.
3. It is necessary to additionally purchase suitable CT and meter according to the specific requirements in parallel connection mode-Scheme B.
4. It is necessary to turn the DIP switch of No. 1 inverter and No. N inverter to “ON” in parallel connection mode.
5. Under parallel connection mode, it is necessary to connect APP to one of inverters and then go to [Console > Other](#) page to enable [Parallel mode](#) on APP.
6. About breakers:  
DC breaker on BATTERY side: 150A  
AC breaker on Backup port  $\geq 50A$   
AC breaker on Inverter side  $\geq 50A$




**DANGER**

Ensure that the inverter and all cables to be installed have been completely powered off during the whole process of installation and connection. Otherwise, fatal injury could be caused by the high voltage.





## 4.1 Grounding

A protective earth (PE) terminal is equipped at the side of the inverter. Please be sure to connect this PE terminal to the PE bar for reliable grounding.



Items	Remark
Screw	M4 X 12mm; 1.2 N·m
Green-yellow wire	$S(\text{green-yellow wire}) \geq S(\text{PE wire in AC cable})$ S is the cross-sectional area. $\geq 10\text{mm}^2$
Cross-sectional area (Green-yellow wire)	OT terminal must be sized to cross-sectional area of green-yellow wire. E.g., if the cross-sectional area of green-yellow wire is $10\text{mm}^2$ , OT8-4 terminal should be chosen.


 <b>WARNING</b>	The inverter must be grounded; otherwise, there may be electric shock risk.
 <b>CAUTION</b>	If the positive pole or negative pole of the PV array is required to be grounded, then the inverter output (to AC grid) must be isolated by transformer in accordance with IEC62109-1, -2 standards.

## 4.2 GRID/BACKUP Connection

Before connecting the GRID/BACKUP terminal, ensure that both the AC terminal and the DC terminal are powered OFF and the PV switch is OFF. Otherwise there is a risk of high voltage shock.

GRID/BACKUP connection please refer to below.

Step 1: Assemble the AC connector and then insert AC connector into GRID/BACKUP port.










### 4.3 Battery Connection

ESS inverter now only supports the lithium/lead-acid battery. The recommended lithium battery brands are as follows: PYLON LPF, Aoboet LPF, Dyness LPF, UZENERGY L051100-A.

This part only describes the battery connection on inverter side. If you need more detailed connection information about the battery side, please refer to the manual of the battery you used.

Before connecting to battery, please install a separate DC breaker (150A; not equipped) between inverter and battery. This will ensure the inverter can be securely disconnected during maintenance.

	<table border="1"> <thead> <tr> <th>Cable Type Specification (recommendation)</th> <th>Battery</th> </tr> </thead> <tbody> <tr> <td>Diameter(D)</td> <td>10<math>\pm</math>0.3 mm</td> </tr> <tr> <td>Cross section(S)</td> <td>25 mm<sup>2</sup></td> </tr> <tr> <td>Strip length (L)</td> <td>~10 mm</td> </tr> <tr> <td>Cable total length</td> <td>≤3 m</td> </tr> </tbody> </table>	Cable Type Specification (recommendation)	Battery	Diameter(D)	10 $\pm$ 0.3 mm	Cross section(S)	25 mm <sup>2</sup>	Strip length (L)	~10 mm	Cable total length	≤3 m	
	Cable Type Specification (recommendation)	Battery										
Diameter(D)	10 $\pm$ 0.3 mm											
Cross section(S)	25 mm <sup>2</sup>											
Strip length (L)	~10 mm											
Cable total length	≤3 m											
<p>Note: Cables mentioned above must be copper and sized to the connectors.</p>	<p><b>a</b> <span style="margin-left: 200px;"><b>b</b></span></p>											
	 <p>Hydraulic Pressure Crimper</p>	 <p>DC Breaker 150A</p>	 <p>+ Red Cable - Black Cable</p> <p>Click</p>									
<p><b>c</b> <span style="margin-left: 100px;"><b>d</b></span> <span style="margin-left: 100px;"><b>e</b></span> <span style="margin-left: 100px;"><b>f</b></span></p>												


 <p><b>WARNING</b></p>	<ul style="list-style-type: none"> <li>• Reverse Polarity will damage the inverter!</li> <li>• Be careful of electric shock and chemical hazards!</li> <li>• To reduce risk of injury, please use the suitable recommended cable size.</li> </ul>
---	---

### Battery Communication Connection

If the battery type is lithium battery which need communication between the inverter and battery management system (BMS), the connection must be installed.


Please refer to section 4.6.1 for details.

### NTC connection for lead-acid battery



### 4.4 PV Connection (N/A for AC Couple Inverter)

PV connection please refer to below.



 **NOTICE**

- Before connection the PV panels, make sure the plug connector have the correct polarity. Incorrect polarity could permanently damage the inverter.
- PV array shouldn't be connected to the grounding conductor.
- The minimum insulation resistance to ground of the PV panels must exceed 18.33kΩ, there is a risk of shock hazard if the requirement of minimum resistance is not met.

 **WARNING**

Please check polarity of PV connectors!  
If polarity reversed, do not try to disconnect any PV connector until the irradiance declines and the DC currents fall below 0.5 A!  
Only then disconnect the PV plugs and correct the polarity before reconnecting.


## 4.5 Meter/CT Connection

You can monitor usage with a meter or a CT.

### 4.5.1 Meter Connection


This section is applicable to non-parallel connection mode only.

ESS inverter supports the meter CHINT-DDSU666 meter by default. The meter is optional.



Before connecting to Grid, please install a separate AC breaker (not equipped) between meter and Grid. This ensures that the inverter can be safely disconnected during maintenance.

The connection diagram of power cable of meter is as shown in the figure below:




Please refer to the meter instruction manual for details.


### 4.5.2 CT Connection

Before connecting to Grid, please install a separate AC breaker (not equipped) between CT and Grid. This will ensure the inverter can be safely disconnected during maintenance.

The connection diagram of power cable of CT is as shown in the figure below:




Please attention to the Current measuring transformer (CT) connection. The arrow on the CT indicates the current flow from grid to inverter. And lead the live line through the detection hole of CT.

 <b>NOTE</b>	<p>The current direction from grid to inverter is defined as positive and current direction from inverter to grid is defined as negative.</p>
--	---

### 4.6 Communication Connection


There are communication interfaces in the communication port on the bottom of the inverter as show below:




Interface		Descriptions
USB		For fast firmware upgrade.
PARAL		4-Pin interface for parallel communication
		A matched resistance switch for parallel communication
RS485		4-Pin interface for RS485 communication
DRM		Demand response mode for Australia application
CT/METER		For Meter communication or Grid current sense.
BMS		Lithium battery communication interface
9-Pin	DO1	Dry contact control (reserved)
	DO2	Dry contact control (reserved)
	RMO	Remote off control
	Temp./Ext. Signal	Temperature sensor terminal of lead-acid battery/External signal
GPRS/WIFI/LAN		For GPRS/WIFI/LAN communication.



### 4.6.1 BMS Connection (Only for Lithium Battery)

 <b>NOTE</b>	<p>This manual <b>ONLY</b> illustrates the pinout sequence of BMS at INVERTER SIDE. For details about the pinout sequence at battery side, see the user manual of the battery you use, and the following pinout diagram of battery side is only for illustration.</p>
---	---

#### Standard RJ45 Pinout



RJ45 Pin Configuration	
Pin	Color
1	White-Orange
2	Orange
3	White-Green
4	Blue
5	White-Blue
6	Green
7	White-Brown
8	Brown

Always face the flat side of the terminal, and count the pin slots from left to right correspond to 1 to 8. Read the pin definitions of both the battery and inverter carefully.

#### Pin definition of terminal

INVERTER:


Inverter	
Pin	Definition
1	RS485_A
2	RS485_B
3	GND_S
4	CAN_H
5	CAN_L
6	GND_S
7	CAN_L
8	CAN_H

BATTERY:

Taking one battery's pin configuration as an example.

Battery Example	
Pin	Definition
1	NC
2	NC
3	GND_S
4	CAN_H
5	CAN_L
6	GND_S
7	NC
8	NC


#### CAN BUS connection principle




### BMS communication cable prepare.

- ① Prepare RJ45 terminals and strip appropriate length of COM cables.
- ② According to pin definitions and cable order, assemble the RJ45 terminals and crimp communication wires. There are two methods to assemble the RJ45 terminals.
- ③ Then label the RJ45 terminals (BAT or INV) to avoid confusion.
- ④ After finishing wire-making, use a multimeter or other specific tool to check if your cable is good, bad, or wired incorrectly.


**Method 1:** Use the INVERTER RJ45 pinout as the standard pinout to crimp wires, then the battery side will be a non-standard one (special pinout). Cut off the other no-used wires (1/2/3/6/7/8) for the battery RJ45 terminal.




**Method 2:** Use the BATTERY RJ45 pinout as the standard pinout to crimp wires, then the inverter side will be a non-standard one (special pinout). Cut off the other no-used wires (1/2/3/4/5/6) for the inverter RJ45 terminal.




### BMS communication cable connection.





**b** Lead the BMS cable through the rubber nut, seal and waterproof cover in turn.



- ① Insert RJ45 terminal into corresponding port.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.


**c**

### 4.6.2 DRMs Connection

DRMs is a shortened form for “inverter demand response modes”. It is a compulsory requirements for inverters in Australia.

Note: With DRMs connection, it is necessary to connect APP to inverter and then go to [Console > Other Setting](#) page to enable [DRM function](#) on APP. Please refer to section 7.2.3.

#### RJ45 Terminal Configuration of DRMs



<b>PIN</b>	1	2	3	4
<b>Function Description</b>	DRM1/5	DRM2/6	DRM3/7	DRM4/8
<b>PIN</b>	5	6	7	8
<b>Function Description</b>	REF	DRM 0/COM	NC	NC

Refer to the following steps:

**a** Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

**c**

- ① Insert RJ45 terminal into corresponding port.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws (1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.


**b** Make the RJ45 terminal according to above function description of each Pin definition. Lead the BMS cable through the rubber nut, seal and waterproof cover in turn.

Don't cut off any communication cables.

Press the DRMs cable in the seal via the side incisions.

### 4.6.3 Meter/CT Connection


#### RJ45 Terminal Configuration of Meter/CT Communication







PIN	1	2	3	4	5	6	7	8
Function Description	RS485_A	RS485_B	RS485_A/ Test +	RS485_B	CT-	CT+	Test-	NC

#### 4.6.3.1 Meter Connection

##### Meter cable connection overview




**Connect meter. Refer to the following steps:**

 <p><b>a</b> Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.</p>	 <p><b>c</b></p> <ol style="list-style-type: none"><li>① Insert RJ45 terminal into corresponding port.</li><li>② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).</li><li>③ Install the seal into the threaded sleeve, fasten the rubber nut.</li></ol>
<p><b>b</b> Make the RJ45 terminal according to above function description of each Pin definition. Lead the meter communication cable through the rubber nut, seal and waterproof cover in turn.</p>  <p><b>!</b> Don't cut off any communication cables.</p>  <p>Press the meter cable in the seal via the side incisions.</p>	

### 4.6.3.2 CT Connection

This section is applicable to non-parallel connection mode and parallel connection-scheme A only.


#### CT cable connection overview



RJ45	CT
Pin3 (Test+)	Green-white
Pin5 (CT-)	Blue-white
Pin6 (CT+)	Green
Pin7 (Test-)	Brown-white

Note:  
Pin3 and Pin7 in the CT are short-circuit connected.

Connect CT. Refer to the following steps:



**a** Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

**b** Make the RJ45 terminal according to above function description of each Pin definition. Lead the CT cable through the rubber nut, seal and waterproof cover in turn.

**c**

- ① Insert RJ45 terminal into corresponding port.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.

⚠ Don't cut off any communication cables.

Press the CT cable in the seal via the side incisions.

### 4.6.4 RS485 Connection

#### 4-Pin Terminal Configuration of RS485 Communication



PIN	A	B	PE	PE
Function Description	RS485_A	RS485_B	PE	PE

Connect RS485. Refer to the following steps:

**a** Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

**c**

- ① Insert 4-Pin terminal into corresponding port.
- ② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).
- ③ Install the seal into the threaded sleeve, fasten the rubber nut.

**b** Make the 4-Pin terminal according to above function description of each Pin definition. Lead the RS485 cable through the rubber nut, seal and waterproof cover in turn.

Labels: RS485 Control Module, RS485 cable, Rubber nut, Seal, Threaded sleeve, Waterproof cover, 4-Pin terminal, Inverter side.

Don't cut off any communication cables.

Press the RS485 cable in the seal via the side incisions.




### 4.6.5 Parallel Communication Connection

#### 4-Pin Terminal Configuration of parallel Communication



PIN	G	S	L	H
Function Description	GND_S	PARA_SYNC	CAN_L	CAN_H


#### Parallel communication cable connection overview



It is necessary to turn the DIP switch of No. 1 inverter and No. N inverter to “ON” in parallel connection mode.


No. 1 Inverter	No. 2 Inverter	.....	No. N Inverter
PinH(CAN_H)	PinH(CAN_H)		PinH(CAN_H)
PinL(CAN_L)	PinL(CAN_L)		PinL(CAN_L)
PinS(PARA_SYNC)	PinS(PARA_SYNC)		PinS(PARA_SYNC)
PinG(GND_S)	PinG(GND_S)		PinG(GND_S)

Refer to the following steps:



Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.

**a**




① Insert 4-Pin terminal into corresponding port.  
② Screw the waterproof cover back to inverter firmly with 4 x M4 screws(1.2N·m).  
③ Install the seal into the threaded sleeve, fasten the rubber nut.

**c**

**b**

Make the 4-Pin terminal according to above function description of each Pin definition.  
Lead the RS485 cable through the rubber nut, seal and waterproof cover in turn.



Another inverter side

Parallel communication cable

Threaded sleeve


4-Pin terminal

Inverter side

Rubber nut

Seal

Waterproof cover


 Don't cut off any communication cables.

Press the Parallel communication cable in the seal via the side incisions.

### 4.6.6 Temp. Ext. Signal/RMO/DRY Connection(s)

#### 9-Pin Terminal Configuration of Auxiliary Communication

Pin123456789



PIN	Function Description
1	NO1 (Normal Open)
2	N1 (Common Pole)
3	NC1 (Normal Close)
4	NO2 (Normal Open)
5	N2 (Common Pole)
6	NC2 (Normal Close)
7	Remote OFF
8	GND_S
9	Temp. : NTC BAT+ (NOT Italy regulation)
	Ext. Signal : External signal (Italy regulation)

Refer to the following steps:

Unscrew the waterproof cover and loosen the rubber nut on waterproof cover.


**a**

**b** Make the 9-Pin terminal according to above function description of each Pin definition for the auxiliary port you want to use.

Lead the Temp. Ext. Signal/RMO/DRY cable(s) through the rubber nut, seal and waterproof cover in turn.

Don't cut off any communication cables.


Press the Temp. Ext. Signal/RMO/DRY cable(s) in the seal via the side incisions.



#### 4.6.7 GPRS/WIFI/LAN Module Connection (Optional)

For details, please refer to the corresponding Module Installation Guide in the packing.

The appearance of modules may be slightly different. The figure shown here is only for illustration.



## 5. System Operation

### 5.1 Inverter Working Mode

The inverter supports several different working modes.

#### 5.1.1 Self Used Mode


Go to the "Hybrid work mode" menu, and select the "Self used mode".

Under Self Used mode, the priority of PV energy consumption will be Load > Battery > Grid, that means the energy produced by PV gives priority to powering local loads, the excess energy is used to charge the battery and the remaining energy is fed into the grid.

This is the default mode to increase self-consumption rate. There are several situations of self-used working mode based on PV energy.


##### a) Wealthy PV Energy

When PV energy is wealthy, the PV energy will be first consumed by loads, the excess energy will be used to charge the battery and then the remaining energy will be fed into the grid.




##### b) Limited PV Energy

When the PV energy is not enough to cover all consumption, the PV energy will be entirely used by loads, and the insufficient part will be supplied by battery. Then still insufficient parts will be supplied by grid.



### c) No PV Input

The inverter will first discharge the battery energy for home load consuming when no PV input( such as in the evening or some cloudy or rainy days). If the demand is not met, the loads will consume grid energy.




### 5.1.2 Feed-in Priority Mode

Go to the "Hybrid work mode" menu, and select the "Feed-in priority mode".

Under this mode, the priority of PV energy consumption will be Load > Grid > Battery, that means the energy produced by PV gives priority to powering local loads, the excess energy is fed into the grid, and the remaining energy is used to charge the battery.


### a) Wealthy PV Energy

When PV energy is wealthy, the PV energy will be first consumed by loads. If there is excess PV power, the power will be fed into grid. If there is still PV energy left after load consuming and grid feeding, then the remaining PV power will be used to charge the battery.




### b) Limited PV Energy

When PV energy is limited and can not meet the feed-in grid power, the battery will discharge to meet it.



**c) No PV Input**

The inverter will first discharge the battery energy for home load consuming when no PV input (such as in the evening or some cloudy or rainy days). If the demand is not met, the loads will consume the grid energy.





### 5.1.3 Back-up Mode

Go to the "Hybrid work mode" menu, and select the "Back-up Mode".

Under this mode, the priority of PV energy consumption will be Battery > Load > Grid.


This mode aims at charging the battery quickly, and at the same time, you can choose whether to allow AC to charge the battery.

#### Forbid AC charging

In this mode, the battery can be charged only with PV power, and the charging power varies with PV power.


#### a) Wealthy PV power

When PV energy is wealthy, PV charges the battery first, then meets the load, and the rest is fed into the grid.



#### b) Limited PV power

When PV energy is limited, PV gives priority to charging the battery, and the grid directly meets the load demand.




### Allow AC charging

In this situation, the battery can be charged both with PV and AC.


#### a) Wealthy PV power

When PV energy is wealthy, PV charges the battery first, then meets the loads, and the rest is fed into the grid.



#### b) Limited PV power

When the PV energy is not enough to charge the battery, the grid energy will charge the battery as supplement. Meanwhile, the grid energy is consumed by loads.




### 5.1.4 Forced Charge/Discharge Function

According to the demands of application, the user can set the inverter to work on forced charge/discharge the battery in any working mode.

Please go to [Console > Hybrid Setting > Work mode](#) to enable [Time-based Control](#) on APP. There are three time periods in which you can set this function. Outside of the set periods, the inverter returns to its original working mode. The forced charge/discharge function has the highest priority. For setting details, refer to Work mode in **Console** section.

The relationship between the forced charge/discharge function and working mode shown as below.



M : Self Use Mode/Feed-in Priority Mode/Back-up Mode

T1: Time period 1 for forced charge/discharge parameter setting

T2: Time period 2 for forced charge/discharge parameter setting

T3: Time period 3 for forced charge/discharge parameter setting

T1, T2, and T3 priority to M.

### 5.1.5 Off Grid Mode


When the power grid is cut off, the system automatically switches to Off Grid mode.

Under off-grid mode, only critical loads are supplied to ensure that important loads continue to work without power failure.

Under this mode, the inverter can't work without the battery.


#### a) Wealthy PV power

When PV energy is wealthy, the PV power will be first consumed by critical load, then charge the battery.



### b) Limited PV power

When PV energy is limited, BACKUP loads are first powered by PV and then supplemented by battery.



#### NOTICE

- Under this mode, please complete the output voltage and frequency settings.
- It is better to choose the battery capacity larger than 100Ah to ensure BACKUP function work normally.
- If BACKUP output loads are inductive or capacitive loads, to make sure the stability and reliability of system, it is recommended to configure the power of these loads to be within 50% BACKUP output power range.

## 5.2 Startup/Shutdown Procedure

### 5.2.1 Startup Procedure

Check that the installation is secure and strong enough, and that the system is well grounded. Then confirm the connections of AC, battery, PV etc. are correct. Confirm the parameters and configurations conform to relevant requirements.

AC Frequency	50/60Hz	PV Voltage	90~530V
Battery Voltage	42~60V	Grid AC Voltage	180~270V

Make sure all the above aspects are right, then follow the procedure to start up the inverter:

- 1) Power on PV.
- 2) Power on the Battery.
- 3) Power on the AC.
- 4) Power on the BACKUP.
- 5) Connect the cell phone App via Bluetooth. Please refer to Section 7.2 for details.
- 6) Click the Power ON in the App for the first time. Please refer to Section 7.2 for details.

### 5.2.2 Shutdown Procedure

According to actual situation, if there is a must to shut-down the running system, please follow below procedure:

- 1) Connect the cell phone App via Bluetooth. Please refer to Section 7.2 for details.
- 2) Click the Power OFF on the App. Please refer to Section 7.2 for details.
- 3) Power off the BACKUP.
- 4) Power off the AC.
- 5) Power off the Battery.
- 6) Power off the PV.
- 7) If you need to disconnect the inverter cables, please wait at least 10 minutes before touching these parts of inverter.

## **6. Commissioning**

It is necessary to make a complete commissioning of the inverter system. This will essentially protect the system from fire, electric shock or other damages or injuries.

### **6.1 Inspection**

Before commissioning, the operator or installer (qualified personnel) must inspect the system carefully and make sure:

- 1) The system is firmly and correctly installed by following the contents and notifications of this manual, and there are enough spaces for operation, maintenance and ventilation.
- 2) All the terminals and cables are in good status without any damages.
- 3) No items are left on the inverter or within the required clearance section.
- 4) The PV, battery pack is working normally, and grid is normal.

### **6.2 Commissioning Procedure**

After inspection and making sure status is right, then start the commissioning of the system.


- 1) Power on the system by referring to the Startup section 5.2.1.
- 2) Setting the parameters on the App according to user's requirement.
- 3) Finish commissioning.

## 7 User Interface

### 7.1 LED/LCD

#### 7.1.1 LED Introduction

This section describes the LED panel. LED indicator includes PV, BAT, GRID, BACKUP, COM, ALARM indicators. PV is N/A for AC couple. It includes the explanation of indicator states and summary of indicator states under the running state of the machine.



LED Indicator	Status	Description
PV	On	PV input is normal.
	Blink	PV input is abnormal.
	Off	PV is unavailable.
BAT	On	Battery is charging. Battery is normal.
	Blink	Battery is discharging (light on 2s and off 2s). Battery is abnormal (light on 1s and off 1s).
	Off	Battery is unavailable.
GRID	On	GRID is available and normal.
	Blink	GRID is abnormal.
	Off	GRID is unavailable.
COM	Blink	Data are communicating.
	Off	No data transmission.
BACKUP	On	BACKUP power is available.
	Blink	BACKUP output is abnormal.
	Off	BACKUP power is unavailable.
ALARM	On	Fault has occurred and inverter shuts down.
	Blink	Alarm has occurred but inverter doesn't shut down.
	Off	No fault.

Details	Code	PV LED	Grid LED	BAT LED	BACKUP LED	COM LED	ALARM LED
PV normal		●	○	○	○	○	○
No PV		○	○	○	○	○	○
PV over voltage	B0						
PV under voltage	B4						
PV irradiation weak	B5	★	○	○	○	○	○
PV string reverse	B7						
PV string abnormal	B3						
On grid		○	●	○	○	○	○
Bypass output		○	●	○	○	○	○
Grid absent	A2	○	○	○	○	○	○
Grid over voltage	A0						
Grid under voltage	A1						
Grid over frequency	A3						
Grid under frequency	A4	○	★	○	○	○	○
Grid abnormal	A6						
Grid over mean voltage	A7						
Neutral live wire reversed	A8						
Battery in charge		○	○	●	○	○	○
Battery unavailable		○	○	○	○	○	○
Battery absent	D1	○	○	○	○	○	○
Battery in discharge		○	○	★★	○	○	○
Battery under voltage	D3						
Battery over voltage	D2						
Battery discharge over current	D4	○	○	★	○	○	○
Battery over temperature	D5						
Battery under temperature	D6						
Communication loss (Inverter - BMS)	D8						
BACKUP output active		○	○	○	●	○	○
BACKUP output inactive		○	○	○	○	○	○
BACKUP short circuit	DB						
BACKUP over load	DC						
BACKUP output voltage abnormal	D7	○	○	○	★	○	○
BACKUP over dc-bias voltage	CP						



Details	Code	PV LED	Grid LED	BAT LED	BACKUP LED	COM LED	ALARM LED
RS485/DB9/BLE/USB		☉	☉	☉	☉	★	☉
Inverter over temperature	C5						
Fan abnormal	C8						
Inverter in power limit state	CL						
Data logger lost	CH	☉	☉	☉	☉	☉	★
Meter lost	CJ						
Remote off	CN						
PV insulation abnormal	B1						
Leakage current abnormal	B2						
Internal power supply abnormal	C0						
Inverter over dc-bias current	C2						
Inverter relay abnormal	C3						
GFCI abnormal	C6						
System type error	C7						
Unbalance Dc-link voltage	C9						
Dc-link over voltage	CA	☉	☉	☉	☉	☉	●
Internal communication error	CB						
Internal communication loss(E-M)	D9						
Internal communication loss(M-D)	DA						
Software incompatibility	CC						
Internal storage error	CD						
Data inconsistency	CE						
Inverter abnormal	CF						
Boost abnormal	CG						
Dc-dc abnormal	CU						

Remark: ● Light on      ○ Light off      ☉ Keep original status  
 ★ Blink 1s and off 1s      ★★ Blink 2s and off 2s


## 7.1.2 LCD Introduction

An LCD screen is optional for this series of inverters. If you choose the LCD screen, the following introduction will help you understand the function of each icon displayed.

**Note:**


The LCD screen will be automatically turned off if there is no operation within 10 mins (which cannot be changed by default). You can tap the ON/OFF button on the side of inverter to wake up the LCD screen.

### Menu Structure Overview



### Icon Introduction-1
















	This icon indicates <b>WIFI</b> connection status.						
	The <b>date and time</b> display information of year, month, day, and hour-time. The ':' between hour and minute flashes once a second.						
	<b>Warning icon</b> only displays when the error occurs. For specific warning code explanation, please refer to the chapter Inverter Troubleshooting.						
	These four icons show <b>different operating status</b> . Please refer to chapter Inverter Working Mode for detailed introduction.						
	This area shows the <b>working conditions and energy flow directions</b> . Please refer to <a href="#">Table Icon Status Description</a> for detailed introduction of each icon displayed.						
	The <b>Energy Bars</b> indicate energy flow direction. Each bar lights up one by one, then turns off when all bars light and repeats this cycle again.						
	The <b>Energy Ring</b> indicates the battery SOC or the current power percentage. Each Energy Ring definition is as follows. <table border="0" style="width: 100%; margin-top: 10px;"> <tr> <td style="width: 50%; vertical-align: top;">  PV Input Power                 </td> <td style="width: 50%; vertical-align: top;"> <b>On-Grid Mode:</b> Grid Output Power  <b>Non On-Grid Mode:</b> Bypass load consumption power + Backup consumption power                 </td> </tr> <tr> <td style="vertical-align: top;">  Battery SOC                 </td> <td style="vertical-align: top;">  Backup                 </td> </tr> <tr> <td style="vertical-align: top;">  Grid undervoltage                 </td> <td style="vertical-align: top;">  Grid overvoltage                 </td> </tr> </table>	PV Input Power	<b>On-Grid Mode:</b> Grid Output Power <b>Non On-Grid Mode:</b> Bypass load consumption power + Backup consumption power	Battery SOC	Backup	Grid undervoltage	Grid overvoltage
PV Input Power	<b>On-Grid Mode:</b> Grid Output Power <b>Non On-Grid Mode:</b> Bypass load consumption power + Backup consumption power						
Battery SOC	Backup						
Grid undervoltage	Grid overvoltage						



## Icon Introduction-2

	<p>The <b>PV icon</b> represents the power of PV.</p>
	<p>The <b>Battery icon</b> represents the current battery charge percentage or the voltage of battery..</p>
	<p>The <b>E-Today icon</b> represents the electricity energy generated today.</p>
	<p>The <b>E-Total icon</b> represents the electricity energy generated in total.</p>
	<p>When the <b>Loading icon</b> is on, it indicates that the device is starting, and the start timer countdown is displayed. The icon lights up a cluster of lights every second until all the lights are on, and then repeats the whole process again.</p>
	<p>The <b>Back-Up icon</b> represents the relevant power, frequency or voltage of Back-Up.</p>
	<p>The <b>Grid icon</b> represents the relevant power, frequency or voltage of the Grid.</p>
	<p>The <b>Smart Load icon</b> represents the power consumption.</p>
	<p>The <b>GEN icon</b> represents the voltage or power of generator.</p>
	<p>The <b>L1 icon</b> represents L1 phase of Grid/Backup/Generator.          The <b>L2 icon</b> represents L2 phase of Grid/Backup/Generator.          The <b>L3 icon</b> represents L3 phase of Grid/Backup/Generator.</p>
	<p>These two areas will display corresponding data of each lit icon mentioned above.</p>

**Table: Icon Status Description**


Icon Status Description			
Icon	Name	Light	Description
	PV	ON	Any PV voltage exists ( it should be higher than the Min. PV Startup Voltage) .
		OFF	PV Voltage is lower than the Min. PV Startup Voltage.
	Grid	ON	Grid Voltage and frequency are normal.
		OFF	Grid overvoltage / undervoltage / overfrequency / underfrequency occurs.
	Battery	ON	Bat. Voltage is higher than the Rated Min. Bat Voltage.
		OFF	Bat. Voltage is lower than the Rated Min. Bat Voltage.
	Back-Up Load	ON	Backup relay is on.
		OFF	Backup relay is off.
	BMS	ON	Battery is set to BMS Type and its communication is normal.
		Blink	BMS communication is abnormal.(The icon indicator on for one second, off for one second)
		OFF	1. Battery is not set to BMS Type. 2. Battery voltage is lower than Rated Min. Voltage
	BACKUP	ON/OFF	Lights up with Back-Up Load icon simultaneously
	Meter/CT	ON	Power Limit is set to CT or Meter in APP, and the CT/Meter communication is normal, the Grid side is running well.
		Blink	When Meter/CT communication is lost, Meter/CT icon on for one second, off for one second)
		OFF	1. Power Limit is not set to CT or Meter. 2. The voltage or frequency of grid side is abnormal.
	Load	ON/OFF	Lights up with Grid icon simultaneously.
	ON	ON	1. Backup relay is on. 2. The inverter works under On-Grid mode. 3. The inverter works under Off-Grid mode.
	OFF	OFF	Non-on working mode.
	Generator / Smart Load / Inverter	From left to right, when the three dots light up, each represents different meanings.	
		When GEN communication is lost, GEN icon will go off.	
	GEN	ON	Generator relay is on.
		OFF	Generator replay is off.
	Generator dot	ON	In APP, the "Gen port" parameters set to "Generator Input" and the generator relay is powered on.
		OFF	APP parameter set to Non 'Genetator Input'.
	Smart Load dot	ON	In APP, the "Gen port" parameters set to "Smart Load Output" and the generator relay is powered on.
		OFF	APP parameter set to Non 'Smart Load Output'.
	Inverter dot	ON	In APP, the "Gen port" parameters set to "Inverte Input" and the generator relay is powered on.
		OFF	APP parameter set to Non 'Inverter Input'.

## 7.2 App Setting Guide

### 7.2.1 App Architecture

It contains “Cloud Login” and “Local Login”.

- Cloud login: APP read data from cloud server through API and display inverter parameters.
- Local login: APP read data from inverter through Bluetooth connection with Modbus protocol to display and configure inverter parameters.



### 7.2.2 Download App

- Scan the QR code on the inverter to download the APP.
- Download APP from the App Store or Google Play.

 Note:

The APP should access some permissions such as the device’s location. You need to grant all access rights in all pop-up windows when installing the APP or setting your phone.




### 7.2.3 Local Login

Step 1. Open the Bluetooth on your own phone and the APP, then click the [Bluetooth Connection](#).

Step 2. To connect the inverter, please choose one of the following three ways:

- Scan machine SN barcode
- Enter SN
- Manual connection


Step 3. Click [OK](#).



#### 7.2.3.1 Quick Setup

The quick setup is required for the first local login.


Step 1. Click the [Quick Setup](#).




Step 2. Firstly please read tips on the screen carefully. Secondly choose the WiFi SSID and enter the WiFi password. Then click the **START THE CONFIGURATION** button and wait for WiFi router loading successfully. Finally click the **Next**.

 Note:


Please use the 2.4G network frequency band for configuration.




Step 3. Set **Standard Code** and **Date and Time** parameters. Then click the **Next**.



Step 4. Set parameters for the inverter to connect to the power limit. Then click the [Next](#).




Step 5. Set parameters for the inverter to connect to the work mode and battery type. Then click the [Next](#).





Step 6. Please click the button to turn on the inverter.



### 7.2.3.2 Chart

The power chart is showed by Day, Month and Year in our APP. Data curves in the following figures are only for illustration.

#### Query Daily Data

Go to [Chart > Day](#) page. It will show the Daily Production or Consumption Curve in this page. You can click anywhere on the graph to see the energy value of any time.




The above combination day chart shows the energy flow:

- PV generation power (Blue)
- Battery discharge and charge power (Red)
- Grid power and feed-in grid power (Purple)
- Load consumption power (Orange)

### Query Monthly Data

Go to [Chart > Month](#) page. It will show the Monthly Production or Consumption Curve in this page. You can click anywhere on the graph to see the energy value of any month.




The above combination month chart shows the the energy flow:

- PV generation capacity (Blue)
- Load consumption capacity (Red)
- Feed-in grid capacity (Purple)
- Grid capacity (Mazarine)

### Query Yearly Data

Go to [Chart](#) > [Year](#) page. It will show the Annually Production or Consumption Curve in this page. You can click anywhere on the graph to see the energy value of any year.






The above combination year chart shows the the energy flow:

- PV generation capacity (Blue)
- Load consumption capacity (Red)
- Feed-in grid capacity (Purple)
- Grid capacity (Mazarine)

### 7.2.3.3 Home


In this page, you can view the basic information of inverter.

Click  to display the warning message.





### 7.2.3.4 Log

Press [Log](#) at the bottom and then go to the history log page ( as shown below ). It contains all the logs for the inverter.



### 7.2.3.5 Console


In this page, you can view the basic information like some version information, do some maintaining operations like turn off/on the inverter and manage data.



## Maintenance

In this page, you can do some maintaining operations like turn off/on the inverter and manage data.


In [Console](#) page, click [Maintenance](#).



## Access Management

In this page, you can switch the login permission.

In [Console](#) page, click [Access Management](#) > [Change User](#) page.




## Communication Setting

In this page, you can set or change the parameters of communication settings: WiFi Setting, RS485 Setting and Ethernet Setting.

In [Console](#) page, click [Communication Setting](#).

 Note:

Setting/modifying these parameters requires logging into an administrator account.





## Grid Parameters

In this page, you can set or change the parameters of Grid side.

In [Console](#) page, click [Grid Parameters](#).

 Note:

Setting/modifying these parameters requires logging into an administrator account.

Grid Parameters	
Standard Code	IN (IEC61727)
First Connect Delay Time(s)	60
Reconnect Delay Time (s)	60
First Connect Power Gradient(%/min)	100
Reconnect Power Gradient(%/min)	100
Frequency High Loss Level_1(Hz)	51
Frequency Low loss Level_1(Hz)	49
Voltage High Loss Level_1(V)	253
Voltage Low Loss Level_1(V)	195.5
Frequency High Loss Time Level_1(ms)	100
Frequency Low loss Time Level_1(ms)	100
Voltage High Loss Time Level_1(ms)	200
Voltage Low Loss Time Level_1(ms)	200
Frequency High Loss Level_2(Hz)	99.9
Frequency Low Loss Level_2 (Hz)	10
Voltage High Loss Level_2(V)	310.5
Voltage Low Loss Level_2(V)	115
Frequency High Loss Time Level_2(ms)	65535
Frequency Low Loss Time Level_2(ms)	65535
Voltage High Loss Time Level_2(ms)	50
Voltage Low Loss Time Level_2(ms)	100
Over Frequency Derating Function	<input checked="" type="checkbox"/>
Over Frequency Power Reduction Droop(%)	5
Grid Over Frequency de-rating Start Point(Hz)	50.2
Over Frequency Derating Reference Power	base on current power
Over Voltage Derating	<input checked="" type="checkbox"/>


### Feature Parameters

In this page, you can set or change the feature parameters, as shown in the figure.

In [Console](#) page, click [Feature Parameters](#).

 Note:

Setting/modifying these parameters requires logging into an administrator account.




### Power Limit

In this page, you can set or change the parameters of power limit.

In [Console](#) page, click [Power Limit](#) page.

 Note:

Setting/modifying these parameters requires logging into an administrator account.




## Reactive Power Control

In this page, you can set or change the Reactive Power Control parameters.

In [Console](#) page, click [Reactive Power Control](#).

 Note:

Setting/modifying these parameters requires logging into an administrator account.



Reactive Power Control	
Reactive Power Control Settling Time (s)	10
Reactive Power Control Mode	cosφ
cosφ	1

## How to Autotest?

Step 1. In **Console** page, click **Grid Parameters** > **Standard Code**, then select the IT (CEI 0-21) or IT (CEI 0-21 ACEA).

Step 2. Back to **Console** page. Refresh the page and enter the **Autotest** page to click **START**.


Step 3. Then the inverter is autotesting. Wait for about 10 minutes, the autotest process will be finished.

Step 4. You can click the **DOWNLOAD** to save the data file if necessary.

 Note:

If the **Autotest** option can't be turned out after the refresh in step 2. Please re-connect after logout.


And then go to **Console** > **Autotest** page to click **START**.



### Other Setting

In this page, you can set other setting parameters.

In [Console](#) page, click [Other Setting](#).



Enable [DRM Function](#) when connecting to DRM.


## Hybrid Setting

In this page, you can set Hybrid Setting parameters.

In [Console](#) page, click [Hybrid Setting](#).


 Note:

Setting/modifying these parameters requires logging into an administrator account.




- Work mode

➤ Work mode: In [Work mode](#) page, there are several work modes are available.



➤ Time-based Control setting: In **Work mode** page, you can also find time-based control function. This function is designed to control the time setting of charging and discharging the inverter. You can set the following parameters based on your requirements:

- Charge and discharge frequency: one time or daily
- Charging start time: 0 to 24 hours
- Charging end time: 0 to 24 hours
- Discharge start time: 0 to 24 hours
- Discharge end time: 0 to 24 hours



- Battery

In **Battery** page, information including battery parameters, charging and discharging management and grid will be listed. Enter corresponding information if necessary.

Battery parameters	
Battery Brand selection	Lead-Acid battery
Battery(Ah)	260
Bulk charging voltage(V)	55
Floating charge voltage(V)	53.2
Stop discharge voltage(V)	46
Lead Acid battery resistance(mΩ)	5
Lead Acid battery charge status	Constant current stage
Battery equalization voltage(V)	56
Battery equalized time(min)	0
Battery equalized timeout(min)	0
Equalization interval(Day)	0
Equalization activated immediately	<input type="checkbox"/>

Charging and discharging management	
Maximum charge power(W)	400
Maximum discharge power(W)	6000
Charge to(%)	100
Discharge to(%)	15
Discharge End SOC(on-grid)(%)	5
Start force charging when reaching(%)	10
Stop force charging when reaching(%)	20
Maximum Grid Forced Charge Power(W)	400

Grid	
Charge by Grid	<input type="checkbox"/>
Maximum grid charge power(W)	6000
Maximum Input power from Grid(W)	9000
Charge by grid to(%)	100

Choose whether to allow the grid to charge the battery, which is prohibited by default. When the battery capacity or voltage reaches the set value, the grid will stop charging the battery.




- Backup Load

In [Backup Load](#) page, if enabling Backup Output, you can set parameters including the range of backup output voltage and Min. initiation/startup battery capacity when off-grid.


Backup Load	
Backup Output	<input checked="" type="checkbox"/>
Minimum backup output voltage(V)	176
Maximum backup output voltage(V)	264
Rated output voltage(V)	230V
Min.initiation/startup battery capacity when off-grid(%)	30

- Other

In **Other** page, options including Parallel Mode, Buzzer ON, Support Normal Load are listed. Enable them when necessary.



## 8. Maintenance

 <b>CAUTION</b>	<p>Before maintaining and commissioning inverter and its peripheral distribution unit, switch off all the charged terminals of the inverter and wait at least 10 minutes after the inverter is powered off.</p>
--	---

### 8.1 Routine Maintenance

Items	Check Content	Maintain Content	Maintenance Interval
Inverter output status	Statistically maintain the status of electrical yield, and remotely monitor its abnormal status.	N/A	Weekly
Inverter cleaning	Check periodically that the heat sink is free from dust and blockage.	Clean periodically the heat sink.	Yearly
Inverter running status	Check that the inverter is not damaged or deformed. Check for normal sound emitted during inverter operation. Check and ensure that all inverter communications is running well.	If there is any abnormal phenomenon, replace the relevant parts.	Monthly
Inverter electrical connections	Check that all AC, DC and communication cables are securely connected; Check that PGND cables are securely connected; Check that all cables are intact and free from aging.	If there is any abnormal phenomenon, replace the cable or re-connect it.	Semiannually

## 8.2 Inverter Troubleshooting

When the inverter has an exception, its basic common warning and exception handling methods are shown below.

Code	Alarm Information	Suggestions
A0	Grid over voltage	1. If the alarm occurs occasionally, possibly the power grid voltage is abnormal for a short time, and no action is required. 2. If the alarm occurs repeatedly, contact the local power station. After receiving approval of the local power bureau, revise the electrical protection parameters settings on the inverter through the App. 3. If the alarm persists for along time, check whether the AC circuit breaker /AC terminals is disconnected or not, or if the grid has a power outage.
A1	Grid under voltage	
A3	Grid over frequency	
A4	Grid under frequency	
A2	Grid absent	Wait till power is restored.
B0	PV over voltage	Check whether the maximum voltage of a single string of input PV modules is greater than the allowable voltage. If the maximum voltage is higher than the standard voltage, modify the number of pv module connection strings.
B1	PV insulation abnormal	1. Check the insulation resistance against the ground for the PV strings. If a short circuit has occurred, rectify the fault. 2. If the insulation resistance against the ground is less than the default value in a rainy environment, set insulation resistance protection on the App.
B2	Leakage current abnormal	1. If the alarm occurs occasionally, the inverter can be automatically recovered to the normal operating status after the fault is rectified. 2. If the alarm occurs repeatedly, contact your dealer for technical support.
B4	PV under voltage	1. If the alarm occurs occasionally, possibly the external circuits are abnormal accidentally. The inverter automatically recovers to the normal operating status after the fault is rectified. 2. If the alarm occurs repeatedly or last a long time, check whether the insulation resistance against the ground of PV strings is too low.
C0	Internal power supply abnormal	1. If the alarm occurs occasionally, the inverter can be automatically restored, no action required. 2. If the alarm occurs repeatedly, pls. contact the customer service center.

C2	Inverter over dc-bias current	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, possibly the power grid voltage is abnormal for a short time, and no action is required.</li> <li>2. If the alarm occurs repeatedly, and the inverter fails to generate power, contact the customer service center.</li> </ol>
C3	Inverter relay abnormal	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, possibly the power grid voltage is abnormal for a short time, and no action is required.</li> <li>2. If the alarm occurs repeatedly, pls. refer to the suggestions or measures of Grid over voltage. and the inverter fails to generate power, contact the customer service center. If there is no abnormality on the grid side, the machine fault can be determined. (If you open the cover and find traces of damage to the relay, it can be concluded that the machine is faulty.) And pls. contact the customer service center.</li> </ol>
CN	Remote off	<ol style="list-style-type: none"> <li>1. Local manual shutdown is performed in APP.</li> <li>2. The monitor executed the remote shutdown instruction.</li> <li>3. Remove the communication module and confirm whether the alarm disappears. If it does, replace the communication module. Otherwise, please contact the customer service center.</li> </ol>
C5	Inverter over temperature	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically restored, no action required.</li> <li>2. If the alarm occurs repeatedly, pls. check the installation site for direct sunlight, good ventilation, and high ambient temperature (Such as installed on the parapet). If the ambient temperature is lower than 45 ° C and the heat dissipation is good, contact the customer service center.</li> </ol>
C6	GFCI abnormal	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, it could have been an occasional exception to the external wiring, the inverter can be automatically recovered, no action required.</li> <li>2. If it occurs repeatedly or cannot be recovered for a long time, pls. contact customer service to report repair.</li> </ol>
B7	PV string reverse	Check and modify the positive and negative polarity of the input of the circuit string.
C8	Fan abnormal	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, pls. restart the inverter.</li> <li>2. If it occurs repeatedly or cannot be recovered for a long time, check whether the external fan is blocked by foreign objects. Otherwise, contact customer service.</li> </ol>
C9	Unbalance Dc-link voltage	1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.
CA	Dc-link over voltage	2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.

CB	Internal communication error	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.</li> </ol>
CC	Software incompatibility	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.</li> </ol>
CD	Internal storage error	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.</li> </ol>
CE	Data inconsistency	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.</li> </ol>
CF	Inverter abnormal	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.</li> </ol>
CG	Boost abnormal	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.</li> </ol>
CJ	Meter lost	<ol style="list-style-type: none"> <li>1. Check the meter parameter Settings</li> <li>2. Local APP checks that the communication address of the inverter is consistent with that of the electricity meter</li> <li>3. The communication line is connected incorrectly or in bad contact</li> <li>4. electricity meter failure.</li> <li>5. Exclude the above, if the alarm continues to occur, please contact the customer service center.</li> </ol>
P1	Parallel ID warning	It is Parallel ID Alarm. Pls. check the parallel communication cable, and check whether any inverter joins or exits online. All inverters are powered off completely, check the line, and then power on the inverters again to ensure that the alarm is cleared.
P2	Parallel SYN signal warning	Parallel synchronization signal is abnormal. Check whether the parallel communication cable is properly connected.
P3	Parallel BAT abnormal	The parallel battery is abnormal. Whether the battery of the inverter is reported low voltage or the battery is not connected.
P4	Parallel GRID abnormal	The parallel grid is abnormal. Whether the grid of the inverter is abnormal.

D2	Battery over voltage	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. Check that the battery overvoltage protection value is improperly set.</li> <li>3. The battery is abnormal.</li> <li>4. If exclude the above, the alarm continues to occur, please contact the customer service center.</li> </ol>
D3	Battery under voltage	<ol style="list-style-type: none"> <li>1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required.</li> <li>2. Check the communication line connection between BMS and inverter (lithium battery).</li> <li>3. The battery is empty or the battery voltage is lower than the SOC cut-off voltage.</li> <li>4. The battery undervoltage protection value is improperly set.</li> <li>5. The battery is abnormal.</li> <li>6. If exclude the above, the alarm continues to occur, please contact the customer service center.</li> </ol>
D4	Battery discharger over current	<ol style="list-style-type: none"> <li>1. Check whether the battery parameters are correctly set.</li> <li>2. Battery undervoltage.</li> <li>3. Check whether a separate battery is loaded and the discharge current exceeds the battery specifications.</li> <li>4. The battery is abnormal.</li> <li>5. If exclude the above, the alarm continues to occur, please contact the customer service center.</li> </ol>
D5	Battery over temperature	<ol style="list-style-type: none"> <li>1. If the alarm occurs repeatedly, please check whether the installation site is in direct sunlight and whether the ambient temperature is too high (such as in a closed room).</li> </ol>
D6	Battery under temperature	<ol style="list-style-type: none"> <li>2. If the battery is abnormal, replace it with a new one.</li> <li>3. If exclude the above, the alarm continues to occur, please contact the customer service center.</li> </ol>
D7	BACKUP output voltage abnormal	<ol style="list-style-type: none"> <li>1. Check whether the BACKUP voltage and frequency Settings are within the specified range.</li> <li>2. Check whether the BACKUP port is overloaded.</li> <li>3. When not connected to the power grid, check whether BACKUP output is normal.</li> <li>4. If exclude the above, the alarm continues to occur, please contact the customer service center.</li> </ol>
D8	Communication error (Inverter-BMS)	<ol style="list-style-type: none"> <li>1. Check whether the battery is disconnected.</li> <li>2. Check whether the battery is well connected with the inverter.</li> <li>3. Confirm that the battery is compatible with the inverter. It is recommended to use CAN communication.</li> <li>4. Check whether the communication cable or port between the battery and the inverter is faulty.</li> <li>5. If exclude the above, the alarm continues to occur, please contact the customer service center.</li> </ol>

D9	Internal communication loss(E-M)	1. Check whether the communication cables between BACKUP, electricity meter and inverter are well connected and whether the wiring is correct 2. Check whether the communication distance is within the specification range
DA	Internal communication loss(M-D)	3. Disconnect the external communication and restart the electricity meter and inverter. 4. If exclude the above, the alarm continues to occur, please contact the customer service center.
CU	Dcdc abnormal	1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, please check: 1) Check whether the MC4 terminal on the PV side is securely connected. 2) Check whether the voltage at the PV side is open circuit, ground to ground, etc. If exclude the above, the alarm continues to occur, please contact the customer service center.
CP	BACKUP over dc-bias voltage	1. If the alarm occurs occasionally, the inverter can be automatically recovered and no action is required. 2. If the alarm occurs repeatedly, the inverter cannot work properly. Pls. contact the customer service center.
DB	BACKUP short circuit	1. Check whether the live line and null line of BACKUP output are short-circuited. 2. If it is confirmed that the output is not short-circuited or an alarm, please contact customer service to report for repair. (After the troubleshooting of alarm problems, BACKUP switch needs to be manually turned on during normal use.)
DC	BACKUP over load	1. Disconnect the BACKUP load and check whether the alarm is cleared. 2. If the load is disconnected and the alarm is generated, please contact the customer service. (After the alarm is cleared, the BACKUP switch needs to be manually turned on for normal use.)



### 8.3 Removing the Inverter




#### WARNING

Before removing DC input connector, double check DC input switch is turned to OFF to avoid inverter damage and personal injury.

Perform the following procedures to remove the inverter:

Step 1. Disconnect all cables from the inverter, including communications cables, DC input power cables, AC output power cables, and PGND cable, as shown below.




PV Connectors Removing Detail




#### NOTE

To remove the PV/GRID/BACKUP connectors, insert the removal tool into the bayonet according to the position indicated in the drawing, press inward, and then take out the connector outward.



GRID/BACKUP Connectors Removing Detail



Step 2. Remove the inverter from the mounting bracket.

Step 3. Remove the mounting bracket.

## 9. Technical Specifications

Model	3K6HB-60	3K68HB-60	4K6HB-60	4K6HB-120	5KHB-60	5KHB-120	6KHB-60	6KHB-120	4K6AC	5KAC	6KAC
<b>Input (PV)</b>											
Max. PV power (W)	6300						9000		N/A		
Max. PV voltage (V)	550						550		N/A		
Max. input current (A)	15/15						15/15		N/A		
Max. short current (A)	20/20						20/20		N/A		
Startup voltage (V)	90						90		N/A		
MPPT voltage range @full load (V)	280-480		200~480	200~480	200~480	200~480	230~480	230~480	N/A		
No. of MPPT trackers	2						2		N/A		
String per MPPT tracker	1						1		N/A		
<b>Input (BAT)</b>											
Compatible battery type	Lithium/Lead-acid							Lithium/Lead-acid			
Norminal battery voltage (V)	48							48			
Battery voltage range (V)	40~65							40~65			
Lithium battery charge curve	Self-adaption to BMS							Self-adaption to BMS			
Max. charge/discharge current (A)	60/60	60/60	120/120	60/60	120/120	60/60	120/120	100/100	100/100	120/120	
Max. charge/discharge power (W)	3000/3000	3000/3000	6000/6000	3000/3000	6000/6000	3000/3000	6000/6000	5000/5000	5000/5000	6000/6000	

Model	3K6HB-60	3K68HB-60	4K6HB-60	4K6HB-120	5KHB-60	5KHB-120	6KHB-60	6KHB-120	4K6AC	5KAC	6KAC
<b>Output (Grid)</b>											
Nominal AC output power (W)	3600	3680	4600	4600	5000	5000	6000	6000	4600	5000	6000
Max.AC output apparent power (VA)	3960	3680	4600	4600	5500	5500	6000	6000	4600	5500	6000
Max.AC output power (PF=1) (W)	3960	3680	4600	4600	5500	5500	6000	6000	4600	5500	6000
Max.AC output current (A)	18	18	22	22	25	25	27.2	27.2	22	25	27.2
Rated AC voltage (V)	220/230/240								220/230/240		
AC voltage range (V)	150~300(adjustable)								150~300(adjustable)		
Rated AC frequency (Hz)	50/60								50/60		
AC frequency range (Hz)	45~55/55~65(adjustable)								45~55/55~65(adjustable)		
Grid connection	Single phase								Single phase		
Power factor	>0.99@rated power(adjustable 0.8LG~0.8LD)								>0.99@rated power(adjustable 0.8LG~0.8LD)		
THDI	<3%								<3%		
<b>Output (Back up)</b>											
Nominal output voltage (V)	230								230		
Nominal output frequency (Hz)	50/60								50/60		
Transfer time (ms)	10(type)/20(max.)								10(type)/20(max.)		
THDV	<3%@100%R load								<3%@100%R load		
Nominal output power (W)	3000	3000	4600	3000	5000	3000	6000	4600	5000	6000	
Nominal output current (A)	13	13	20	13	21.7	13	26	20	21.7	26	

Model	3K6HB-60	3K68HB-60	4K6HB-60	4K6HB-120	5KHB-60	5KHB-120	6KHB-60	6KHB-120	4K6AC	5KAC	6KAC
<b>Protection</b>											
Protection category	Class I						Class I				
AC overcurrent protection	Support						Support				
AC short circuit protection	Support						Support				
Leakage current protection	Support						Support				
AC overvoltage category	III						III				
PV overvoltage category	II						N/A				
Surge Arrester	DC Type III; AC Type III						AC Type III				
PV switch	Support						N/A				
Anti-islanding protection	Support (Frequency shift)						Support (Frequency shift)				
DC reverse detection	Support						N/A				
Insulation detection	Support						Support				
<b>General</b>											
Topology	Transferless						Transferless				
Max. operation altitude (m)	4000						4000				
Ingress protection degree	IP65						IP65				
Operating temperature range (°C)	-25~60						-25~60				
Noise emission (dB)	<30	<30	<35	<30	<35	<30	<35	<35	<35	<35	<35
Weight (kg)	16	20	25	20	25	20	25	20	25	20	20

Model	3K6HB-60	3K68HB-60	4K6HB-60	4K6HB-120	5KHB-60	5KHB-120	6KHB-60	6KHB-120	4K6AC	5KAC	6KAC
Relative humidity (%)	0~100								0~100		
Cooling concept	Natural								Natural		
Mounting	Wall bracket								Wall bracket		
Dimensions (W*H*D)	(515*487*175)mm								(515*487*175)mm		
PV connection way	MC4/H4								N/A		
Battery connection way	Dedicated DC connector								Dedicated DC connector		
AC connection way (Grid & back up)	Dedicated AC connector								Dedicated AC connector		
<b>Display &amp; Communication</b>											
Display	LED+APP, (optional) LCD								LED+APP, (optional) LCD		
Communication interface	BMS (CAN/RS485)/LAN/WIFI/DRMs/Meter (RS485)								BMS (CAN/RS485)/LAN/WIFI/DRMs/Meter (RS485)		
<b>Certification</b>											
Grid	IEC61727; VDE-AR-N4105; IEC62116; CEI0-21; EN50549-1								IEC61727; VDE-AR-N4105; IEC62116; CEI0-21; EN50549-1		
Safety	IEC62109-1&2; IEC62477-1; IEC62040-1								IEC62109-1&2; IEC62477-1; IEC62040-1		
EMC	IEC61000-6-1/2/3/4								IEC61000-6-1/2/3/4		
<b>Warranty</b>											
Period (Years)	5/10 (optional)								5/10 (optional)		

As the technology is constantly updated and improved, the illustrations in this document are for reference only. Contents including illustrations in this document are subject to change without notice. All rights reserved